

NEW YORK STYLE HOT DOG CART

INSTRUCTIONS

- ♦ FILL LARGE PAN ABOUT HALFWAY WITH HOT WATER.
- ♦ FILL SMALL PAN WITH ABOUT 2" OF HOT WATER.
- ♦ PLACE HOT DOGS IN LARGE PAN.
- ♦ PLACE SAUERKRAUT & ONIONS IN BAIN MARIE POTS AND PLACE POTS INTO SMALL PAN.
- ♦ OPEN STERNO DRAWER AND LIGHT STERNO. CLOSE DRAWER.
- ♦ LET HOT DOGS COOK FOR 20 TO 30 MINUTES.
- ♦ REPLACE STERNO AS NECESSARY.